

## Rat Hepatitis B Core Antigen (HbcAg) ELISA Kit

**Catalog No:** abx055691

**Size:** 96T

**Range:** Qualitative

**Sensitivity:** Qualitative

**Storage:** Store at 2-8°C for 6 months.

**Application:** The qualitative detection of HbcAg in Rat serum, plasma, tissue homogenates, cell lysates and other biological fluids.

**Principle of the Assay:** This kit is based on sandwich enzyme-linked immuno-sorbent assay technology. An antibody is pre-coated onto a 96-well plate. Controls, test samples and HRP-conjugated reagent are added to the wells and incubated. Unbound conjugates are removed using wash buffer. TMB substrate is used to quantify the HRP enzymatic reaction. After TMB substrate is added, only wells that contain sufficient HbcAg will produce a blue coloured product, which then changes to yellow after adding the acidic stop solution. The intensity of the yellow colour is proportional to the HbcAg amount bound on the plate. The Optical Density (OD) is measured spectrophotometrically at 450 nm in a microplate reader, from which the presence of HbcAg can be determined.

### Kit Components

- Pre-coated 96-Well Microplate: 12 x 8
- Positive Control: 0.5 ml
- Negative Control: 0.5 ml
- Sample Diluent Buffer: 6 ml
- Wash Buffer: (20X) 25 ml
- Detection Reagent: 10 ml
- TMB Substrate A: 6 ml
- TMB Substrate B: 6 ml
- Stop Solution: 6 ml
- Plate Sealer: 3
- Hermetic Bag: 1

### Materials Required But Not Provided

- 37°C incubator
- Multi and single channel pipettes and sterile pipette tips
- Squirt bottle or automated microplate washer
- 1.5 ml tubes
- Distilled water
- Absorbent filter papers
- 100 ml and 1 liter graduated cylinders
- Microplate reader (wavelength: 450 nm)
- ELISA Shaker

## Protocol

### A. Sample Preparation

Analyse immediately or store samples at 2-8°C (within 24 hrs). For long term storage, aliquot and store at -20°C or -80°C. Avoid multiple freeze-thaw cycles.

- **Serum:** Samples should be collected into a serum separator tube. Coagulate the serum by leaving the tube undisturbed in a vertical position overnight at 4°C or at room temperature for up to 1 hr. Centrifuge at approximately 1000 × g for 20 mins. If precipitate appears, centrifuge again. Assay immediately or aliquot and store at -20°C or -80°C.
- **Plasma:** Collect plasma using EDTA or citrate as an anticoagulant. Centrifuge for 15 mins at 1000 × g, within 30 mins of collection. If precipitate appears, centrifuge again. Avoid hemolytic samples.
- **Tissue Homogenates:** The preparation of tissue homogenates will vary depending upon tissue type – this is just an example. Rinse tissues with ice-cold PBS to remove the excess of blood. Weigh before homogenization. Finely mince tissues and homogenize with a tissue homogenizer on ice in PBS and sonicate the cell suspension. Centrifuge the homogenates at 10000 × g for 5 mins and collect the supernatant.
- **Cell Lysates:** Detach adherent cells with trypsin and collect by centrifugation and remove the supernatant. Wash the cells three times in ice-cold PBS and re-suspend cells in PBS. Lyse the cells by ultra-sonification 4 times, or freeze at -20°C and thaw to room temperature 3 times. Centrifuge at 1500 × g for 10 mins at 2-8°C to remove cellular debris. Collect the supernatant.
- **Other Biological Fluids:** Centrifuge at approximately 1000 × g for 20 mins to remove precipitate. Analyse immediately or aliquot and store at -20°C or -80°C.

### Notes:

- Samples must be diluted so that the expected concentration falls within the kit's range. **Analyse samples at a 5-fold (1/5) dilution (i.e. add 10 µl of sample to 40 µl of Sample Diluent Buffer).**
- Store frozen samples undiluted. Once ready to analyse, thaw samples and dilute.
- Fresh samples, or recently obtained samples, are recommended to prevent protein degradation and denaturation that may lead to erroneous results.
- NaN<sub>3</sub> cannot be used as a test sample preservative, since it inhibits HRP.
- If possible, prepare solid samples using sonication and/or homogenization, as lysis buffers may (on occasion) interfere with the kit's performance.
- If a sample is not indicated in the manual applications, a preliminary experiment to determine the suitability of the kit will be required.

### B. Reagent Preparation

**Wash Buffer:** Dilute the concentrated Wash buffer 20-fold (1/20) with distilled water (i.e. add 20 ml of concentrated wash buffer into 380 ml of distilled water). If crystals have formed in the concentrated Wash Buffer, warm to room temperature and mix gently until the crystals have completely dissolved.

### C. Assay Protocol

Equilibrate the kit components and samples to room temperature prior to use. It is recommended to measure in duplicate.

1. Set 2 positive and 2 negative control, test sample and control (zero) wells on the pre-coated plate respectively, and record their positions. *Add the solution to the bottom of each well without touching the side walls. Pipette the standards and samples up and down to mix before adding to the wells. Avoid foaming or bubbles.*
2. Aliquot 50 µl of negative and 50 µl positive control into the set wells. Aliquot 50 µl of sample diluent buffer in the control (zero) blank well.
3. Aliquot 50 µl of appropriately diluted sample (diluted 5-fold) into the test sample wells. Gently tap the plate to mix, or use a microplate shaker.
4. Cover the plate with a plate sealer and incubate for 30 mins at 37°C.
5. Remove the cover and discard the liquid. Wash the plate 5 times with 1X Wash Buffer. *Fill each well completely with Wash buffer (300 µl) using a multi-channel Pipette or autowasher (1-2 mins soaking period is recommended). Complete removal of liquid at*

# Instructions for Use

Version: 4.0.0

Revision date: 18 Mar 2021



*each step is essential for good performance. After the final wash, remove any remaining Wash Buffer by aspirating or decanting. Invert the plate and blot it against clean absorbent paper towels.*

6. Aliquot 100  $\mu$ l of Detection Reagent to each well (except the blank well). Cover the plate with a plate sealer and incubate for 1 hr at 37°C.
7. Remove the cover, discard the liquid, and repeat the wash process as described above, 5 times.
8. Aliquot 50  $\mu$ l of TMB Substrate A and 50  $\mu$ l of TMB Substrate B into each well. Cover the plate with the plate sealer and gently tap the plate to mix thoroughly. Incubate at 37°C for 10-15 mins. The incubation time is for reference only, the optimal time should be determined by end user. Avoid exposure to light.
9. Aliquot 50  $\mu$ l of Stop Solution into each well. It is important that the Stop Solution is mixed quickly and uniformly throughout the microplate to inactivate the enzyme completely.
10. Ensure that there are no fingerprints or water on the bottom of the plate, and that the fluid in the wells is free of bubbles. Measure the OD at 450 nm immediately.

## Data Analysis:

- Mean OD of the Positive Control should be  $\geq 1.00$ .
- Mean OD of the Negative Control should be  $\leq 0.15$ .
- CUT OFF value = Negative Control + 0.15

If the Positive Control value is  $\geq 1.00$ , and the Negative Control value is  $\leq 0.15$ , the test is valid, otherwise, the test is invalid.

If OD of Samples < CUT OFF, the test samples are considered negative.

If OD of Samples  $\geq$  CUT OFF, the test samples are considered positive.

## Precautions:

- Before using the kit, centrifuge the tubes to bring down the contents trapped in the lid.
- Do not leave the wells uncovered for extended periods between incubations. The addition of reagents for each step should not exceed 10 mins.
- Ensure that the plate is properly sealed or covered during the incubation steps, and that the time and temperature are controlled.
- Do not reuse pipette tips and tubes.
- Do not use expired components, or components from a different kit.
- The TMB substrate should be used under sterile conditions, and light exposure should be minimised. Unused substrate should be colorless, or a very light yellow in appearance. Do not discard any residual solution back into the vial.
- Please note that this kit is optimised for detection of native samples, rather than recombinant proteins or synthetic chemicals. We are unable to guarantee detection of recombinant proteins, as they may have different sequences or tertiary structures to the native protein.